

CONFIDENTIAL B

MEDIATEK

P40 CA-LTM

Introduction & Usage




Outline

1. Function Overview
2. Feature特點
3. 調整與算法說明
4. Tool 使用說明

CA-LTM: Content-Aware Local Tone Mapping

- Block-based approach to local contrast enhancement
- Content-aware algorithm making details stand out



Outline

1. Function Overview
2. Feature特點
3. 調整與算法說明
4. Tool 使用說明

Feature 特點

1. 不影響整體平均亮度
2. 局部對比/細節強化
3. 膚色/平坦區 保護機制
4. 雜訊影響小

不影響整體平均亮度

- 即使強度不同，整體平均亮度皆一致




OFF



DEFAULT




STRONG



局部對比/細節強化






局部對比/細節強化





膚色/平坦區 保護機制


- 可針對膚色/平坦區保護，降低強化效果





膚色/平坦區 保護機制

- 可針對膚色/平坦區保護，降低強化效果





雜訊影響小





雜訊影響小




Outline

1. Function Overview
2. Feature特點
3. 調整與算法說明
4. Tool 使用說明

CA-LTM Software Flow






Histogram Equalization (HE) (1/5)



Histogram Equalization (HE) (2/5)

- Strength = 0 NO HE weight
- Larger Strength Larger HE weight



Histogram Equalization (HE) (3/5)

Strength = 0, (CA-LTM OFF)



Histogram Equalization (HE) (4/5)

Strength = 5 (recommend)

Strength : 5



Histogram Equalization (HE) (5/5)

Strength = 8 (Strong)




Skin Protection (1/5)



Input



Dark scene
→ Skin luma enhanced




Bright scene
→ Skin luma reduced

Skin Protection (2/5)

■ Concept

1. Detect skin color by HSY of each pixel.
2. Set weighting of skin protection for blocks.



Skin Protection (3/5)

CA-LTM OFF



Skin Protection (4/5)

CA-LTM ON, w/o Skin Protection



Skin Protection (5/5)

CA-LTM ON, w/ Skin Protection


SkinWeight : 10



Flat Region Protection (1/4)

■ Concept

1. Detect small difference of neighboring pixel as “flat region”.
2. Set weighting of flat region protection for blocks.



Flat Region Protection (2/4)



CA-LTM OFF



Flat Region Protection (3/4)



CA-LTM ON, w/o Flat Region Protection



Flat Region Protection (4/4)



CA-LTM ON, w/ Flat Region Protection





Outline

1. Function Overview
2. Feature特點
3. 調整與算法說明
4. Tool 使用說明


Imagiq Simulator

調整彈性
弱到強分成10組

1. Strength 0 ~10
2. Flat Weight 0~10
3. Skin Weight 0~10



儲存/載入MDP Reg



MEDIATEK

everyday genius