

Outline

- I. Module Spec
- II. Module Select
- III. Basic tuning verify



CONFIDENTIAL B

I. Module Spec



CONFIDENTIAL B

AE Basic Sensor Check

Version: V1.0

Release date: 2017-05-15

Document Revision history

Revision	Date	Description
V1.0	2017-05-12	<ul style="list-style-type: none">• First version

Outline

- Purpose
- Raw Data Collection Method
- Raw Data Analysis
- Q&A

PURPOSE


Purpose

- This document provides an image sensor specification for:
 - Bayer + Bayer dual cam modules.
 - Bayer + Mono dual cam modules
- It describes image sensor **linearity check method & Color Relation(B+M only)** for dual camera modules.
- Image sensor in dual camera must satisfy this specification, then it can be used for dual camera.

LINEARITY CHECK

Environment Setting

- Light condition requirements:
 - Uniform & stable light source.
 - Color temperature: between 5000K ~ 6500K.
 - Brightness: LV10
 - Recommended light source: DNP Light box




Camera Setting

- Camera Setting:
 - Shading: OFF
 - OB: OFF
 - Check image area: Center 100*100 pixels

Exposure/Gain

- This specification needs several capturing with different exposure/gain settings.
 - Item1: **Fix gain** and change exposure time.
 - Increase exposure time and capture raw.
 - The increased time step interval is:
 - 8333 us if light box 60 Hz
 - 5000 us if light box 50 Hz or else.
 - Item2: **Fix exposure time** and change sensor gain.
 - Increase sensor gain and capture raw.
 - The increase gain interval is minimum sensor register step.
 - **Increase/decrease rule:**
 - **Increase:** Analog gain first, and then digital gain.
 - **Decrease:** Digital gain first, and then analog gain.




Check Item 1

- Check item 1:
 1. Set **main2** sensor fixed 1x gain
 2. Set **main2** exposure time (T) to achieve G-channel/W-channel around 8~12 digital value in 10-bit, and this value is after OB.
 3. Set main1 camera with the same exposure setting as **main2**.
 4. Capture raw images for dual camera.
 5. Increase dual camera exposure time 5ms, and capture raw images for dual camera.
 6. Repeat step 5. for capture raw until exposure time maximum or image saturation.
- Collect data:
 - A serial raw images with different exposure time interval 5ms for dual camera.

Check Item 2

- Check item 2:
 1. Set **main2** sensor fixed 32x gain.
 2. Set **main2** exposure time (T) to achieve G-channel/W-channel saturation level(95%~99%), and this value is after OB.
 3. Set main1 camera with the same exposure setting as **main2**.
 4. Capture raw images for both camera.
 5. Decrease both camera sensor gain with minimum register step, and capture raw images for both camera. (please follow the “**Gain increase/decrease rule**” to +/- gain)
 6. Repeat step 5. until gain 1x.



- Collect data:
 - A serial raw images with different gain for dual camera.

RAW DATA ANALYSIS

Raw Data Analysis

- Use tool to see if the capture result can pass spec.
- Here provide a Tool folder, and it contains:
 - DLLUsageExample:
 - Put dual camera raw data in specified folders with proper naming, this tool can output the verification result.

Raw Data File Folder & Naming Rule

- Put main1 raw files in “DIIUsageExample/bin/TestData/Sensor1” folder
- Put main2 raw files in “DIIUsageExample/bin/TestData/Sensor2” folder
- Rename File, the naming rule as below:

- **Naming rule for Check item 1:**

ExposureShutter_RGB_widthxheight_xxxxxx.raw

- for Bayer raw files (xxxxxx could be arbitrary extra information, but not too long(<20 characters))
- Ex. 10000_RGB_4208X3120_20161207_161100.raw

ExposureShutter_Mono_widthxheight_xxxxxx.raw

- for mono raw files (xxxxxx could be arbitrary extra information, but not too long (<20 characters))
- Ex. 10000_Mono_4208X3120_20161207_161100.raw

- **Naming rule for Check item 2:**

SensorGain_RGB_widthxheight_xxxxxx.raw

- for Bayer raw files (xxxxxx could be arbitrary extra information, but not too long(<20 characters))
- Ex. 8x_RGB_4208X3120_20161207_161100.raw

SensorGain_Mono_widthxheight_xxxxxx.raw

- for mono raw files (xxxxxx could be arbitrary extra information, but not too long (<20 characters))
- Ex. 8x_Mono_4208X3120_20161207_161100.raw

Raw Data File Folder & Naming Rule

■ Example:

Bayer raw folder				
Name	Date modified	Type	Size	
1.231x_RGB_4208X3120_20161208_110023.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
1.515x_RGB_4208X3120_20161208_110022.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
1.866x_RGB_4208X3120_20161208_110021.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
1x_RGB_4208X3120_20161208_110024.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
2.297x_RGB_4208X3120_20161208_110020.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
2.828x_RGB_4208X3120_20161208_110019.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
3.482x_RGB_4208X3120_20161208_110018.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
4.287x_RGB_4208X3120_20161208_110017.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
5.278x_RGB_4208X3120_20161208_110016.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
6.498x_RGB_4208X3120_20161208_110015.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
8x_RGB_4208X3120_20161208_110013.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
9.849x_RGB_4208X3120_20161208_110012.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
12.125x_RGB_4208X3120_20161208_110012.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
14.928x_RGB_4208X3120_20161208_110011.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	
16x_RGB_4208X3120_20161208_110009.raw	2016/12/8 上午 11:...	RAW File	25,643 KB	

Mono raw folder				
Name	Date modified	Type	Size	
1.231x_Mono_4208X3120_20161207_16110...	2016/12/7 下午 04:...	RAW File	25,643 KB	
1.515x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
1.866x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
1x_Mono_4208X3120_20161207_161101.raw	2016/12/7 下午 04:...	RAW File	25,643 KB	
2.297x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
2.828x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
3.482x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
4.287x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
5.278x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
6.498x_Mono_4208X3120_20161207_16105...	2016/12/7 下午 04:...	RAW File	25,643 KB	
8x_Mono_4208X3120_20161207_161050.raw	2016/12/7 下午 04:...	RAW File	25,643 KB	
9.849x_Mono_4208X3120_20161207_16104...	2016/12/7 下午 04:...	RAW File	25,643 KB	
12.125x_Mono_4208X3120_20161207_1610...	2016/12/7 下午 04:...	RAW File	25,643 KB	
14.928x_Mono_4208X3120_20161207_1610...	2016/12/7 下午 04:...	RAW File	25,643 KB	
16x_Mono_4208X3120_20161207_161045.r...	2016/12/7 下午 04:...	RAW File	25,643 KB	

Raw Data Analysis

Configure file


- Find *.ini file “LibMtkSensorQualification” in folder “DllUsageExample\bin”

名稱	修改日期	類型	大小
TestData	2016/3/15 上午 1...	檔案資料夾	
ApplicationExample	2016/1/22 下午 0...	應用程式	18 KB
ApplicationExample	2016/1/22 下午 0...	Program Debug ...	547 KB
LibMtkSensorQualification.dll	2016/3/14 下午 0...	應用程式擴充	448 KB
LibMtkSensorQualification	2016/3/14 下午 0...	組態設定	3 KB

Raw Data Analysis

Edit Configure file

- Notice:
 - For B+B dual camera: Keep only B+B setting and remove B+M part.
 - For B+M dual camera: keep B+M setting and remove B+B part.



Raw Data Analysis

Run Test

- Execute “ApplicationExample.exe” in folder DllUsageExample\bin
 - You’ll see the process window as below, and there will be three log files generated:
 - log_color_byaer_mono.txt
 - log_linear_bayer_bayer.txt
 - log_linear_bayer_mono.txt
 - Only one log file that meets your sensor type should be considered (log_linear_bayer_bayer.txt or log_linear_bayer_mono.txt) and ignore the rest files

```
===== Test Start =====

Start LinearityCheckDoubleBayer
Calculating File 15/15
Start LinearityCheckBayerMono
Calculating File 15/15
Start ColorRelCheckBayerMono
Calculating File 1/15
Error: ROI file: 1.231x_RGB_4208X3120_20161208_110023.roi not exist.

===== Results =====

linearDoubleBayerPass Fail!!
linearBayerMonoPass Fail!!
colorBayerMonoPass Fail!!

See log files for detail:
bin\log_linear_bayer_bayer.txt
bin\log_linear_bayer_mono.txt
bin\log_color_byaer_mono.txt

Press any keys to exit.
```

Raw Data Analysis Log File

- Output
 - Pass / fail (each set must meet Criteria: $\pm 3\%$)
 - Log File Format

```
B+B Sensor
[Avg.] Avg. B1/B2, G1/G2,R1/R2
AvgRatio: B:0.644428, G:1.424150, R:0.672489
=====
[RawSet 1]
Sensor1: B:172.034805, G:239.882599, R:177.527603
Sensor2: B:253.643600, G:165.266006, R:251.346405
Ratio1/2: BB:0.678254, GG:1.451494, RR:0.706307
RatioVar: BB:5.2%, GG:1.9%, RR:5.0%
Result:Failed
=====
[RawSet 2]
Sensor1: B:181.913193, G:255.532806, R:187.817200
Sensor2: B:281.697205, G:179.856400, R:278.961212
Ratio1/2: BB:0.645776, GG:1.420760, RR:0.673274
RatioVar: BB:0.2%, GG:-0.2%, RR:0.1%
Result:Pass
=====
...
B+W Sensor
[Avg.]
AvgRatio: GB:1.407280, GR:1.360961, WB:1.267102, WG:0.900370,
WR:1.225411
=====
Avg. G/B, G/R, W/B
Avg. W/G, W/R
=====
[RawSet 1]
Bayer: B:172.034805, G:239.882599, R:177.527603
Mono: W:208.880493
RatioB/B: GB:1.394384, GR:1.351241
RatioVar: GB:-0.9%, GR:-0.7%
RatioM/B: WB:1.214176, WG:0.870761, WR:1.176609
RatioVar: WB:-4.2%, WG:-3.3%, WR:-4.0%
Result:Failed
=====
[RawSet 2]
Bayer: B:181.913193, G:255.532806, R:187.817200
Mono: W:230.092804
RatioB/B: GB:1.404696, GR:1.360540
RatioVar: GB:-0.2%, GR:-0.0%
RatioM/B: WB:1.264849, WG:0.900443, WR:1.225089
RatioVar: WB:-0.2%, WG:0.0%, WR:-0.0%
Result:Pass
=====
...
```

B+B statistic values of two sensors with the same exposure shutter

B+M statistic values of two sensors with the same exposure shutter

Raw Data Analysis

Analysis Of Failed Case

- If test result is failed:
 - Check if *.ini file setting is proper (ex. bit depth, OB value, ROI area...)
 - Check if exposure value(shutter time) of that case is valid for both sensors.
 - Further, need to be discussed.

Q&A

- **Q1:** When camera sensor/lens of dual cam are different, the same exposure setting for both cam will have different brightness results in 2 camera, even to be over-exposure, is that OK?
- **A1:** Yes, it is OK.

Q&A

- **Q2:** If the gain increase/decrease interval is very small, the test will need hundreds of captures. Is it OK for analyzing tool to input so many raw files?
- **A2:** Yes, it is OK.

- **Q3:** If gain interval in digital is 1x, 2x, 4x...., and makes gain changing interval bigger than analog gain, for example, 1x, 1.25x, 1.5x... 8x, 16x, 32x, is it OK?
- **A3:** Yes, it is OK.

Q&A

- **Q4:** If test with phone, how to set the exposure setting?
- **A4:** Please use following ADB commands to set exposure time, analog gain(sensor gain), and digital gain (isp gain)..

```
adb shell setprop debug.ae_mgr.enable 1
```

```
adb shell setprop debug.ae_mgr.preview.update 1
```

```
adb shell setprop debug.ae_mgr.shutter 10
```

← exposure time: unit: us, i.e. 8333 us

```
adb shell setprop debug.ae_mgr.sensorgain 2048
```

← analog gain, 1024 base, i.e. 1x =1024, 2x =2048...

```
adb shell setprop debug.ae_mgr.ispgain 1024
```

← digital gain, 1024 base, i.e. 1x =1024, 2x =2048...

COLOR RELATION

Color Relation Check

Step 1 : Capture Pure Raw of Bayer & Mono Sensor

Scenario:

ColorChecker put in the center of image (occupy 1/9 of whole image)

Lighting condition :

D65, CWF, TL84, A, Hor

Exposure control:

Control exposure make

Mono sensor #19 around saturation level * 80%

Bayer's exposure is **the same** with Mono



Total: 10 "Pure Raw" data (Bayer = 5, Mono = 5)

Color Relation Check

Step 2 : Put Bayer & Mono Raw Data in Different Folders With Proper Naming

- You can put the captured Bayer raw files in arbitrary folder and put mono raw files in another, but file naming must follow the rule, and some example's shown below

- Naming rule:

Lightsource-B_widthxheight_bit depth_bayer type.raw for Bayer raw files

Ex. D65-B_4208x3120_10_3.raw

Lightsource-M_widthxheight_bit depth_bayer type.raw for Mono raw files

Ex. D65-M_4208x3120_10_3.raw

5 sets of
1-by-1 raw files

名稱	修改日期	類型	大小
A-B_4208x3120_10_3.raw	2015/1/1 上午 02:16	RAW File	25,643 KB
CW-B_4208x3120_10_3.raw	2015/1/1 上午 02:10	RAW File	25,643 KB
D65-B_4208x3120_10_3.raw	2015/1/1 上午 02:09	RAW File	25,643 KB
Ho-B_4208x3120_10_3.raw	2015/1/1 上午 02:17	RAW File	25,643 KB
TL84-B_4208x3120_10_3.raw	2015/1/1 上午 02:15	RAW File	25,643 KB

名稱	修改日期	類型	大小
A-M_4208x3120_10_0.raw	2015/1/1 上午 02:16	RAW File	25,643 KB
CW-M_4208x3120_10_0.raw	2015/1/1 上午 02:10	RAW File	25,643 KB
D65-M_4208x3120_10_0.raw	2015/1/1 上午 02:09	RAW File	25,643 KB
Ho-M_4208x3120_10_0.raw	2015/1/1 上午 02:17	RAW File	25,643 KB
TL84_M_4208x3120_10_0.raw	2015/1/1 上午 02:16	RAW File	25,643 KB

Color Relation Check

Step 3 : Edit .ini File

- Find .ini file in **ColorRelationTestProgram** Folder

名稱	修改日期	類型	大小
logs	2016/3/6 下午 03...	檔案資料夾	
TestData	2016/3/6 下午 03...	檔案資料夾	
LibMtkSensorQualification.dll	2016/2/14 下午 04...	應用程式擴充	448 KB
LibMtkSensorQualification	a. Find .ini file	組態設定	2 KB
MtkSensorQualificationGui	2016/2/26 下午 0...	應用程式	66 KB


b. Find the tag "DualCamColorRelationBayerMono"

```
[DualcamcolorRelationBayerMono]
Bayerwidth = 4208;           Fill in Bayer Sensor Information
BayerHeight = 3120;
BayerBitDepth = 12;
BayerObValue = 64;           → OB value, base on raw data bit depth
BayerRawPattern = 3 ;BAYER_B_FIRST=0, BAYER_GB_FIRST=1, BAYER_GR_FIRST=2, BAYER_R_FIRST=3, MONO=4
Monowidth = 4208;
MonoHeight = 3120;           Fill in Mono Sensor Information
MonoBitDepth = 12;
Monoobvalue = 64;           → OB value, base on raw data bit depth
CriterionRatio = 0.05;       → Pass Criterion, DO NOT Modify it!
```

c. Close .ini file after editing


Color Relation Check

Step 4 : Execute Tool



Color Relation Check

Step 5: Load Raw Data




Bayer sensor 5 raw data
(D65,CWF,TL84,A,HOR)

Mono sensor 5 raw data
(D65,CWF,TL84,A,HOR)

Color Relation Check


Step 6: Get Image Information



Color Relation Check

Step7: Check Result Log File

Press qualify button to generate result



You could check log file in folder ColorRelationTestProgram\logs for more detail

[Environment]
BayerPath: F:\SW3\DualCamTech\Titan-meeting\SensorVerifyDemo0215\ColorRelationTestProgram\TestData\sensor1\
MonoPath: F:\SW3\DualCamTech\Titan-meeting\SensorVerifyDemo0215\ColorRelationTestProgram\TestData\sensor2\
[Coefficients]
Conversion formula: $W = xR + yG + zB$
RGB to W coefficients: $x: 0.9165445, y: 0.898799, z: 1.118138$
Raw bit depth: 10
Pass Criterion: $|W/RGBtoW|/1024 < 5.00\%$

x,y,z coefficients

Test information

=====
[RawSet 1]
[ColorCell#1]
Bayer: B:35.540779, G:98.949257, R:104.633423
Mono: W:214.500946
RGBtoW :224.576233
Ratio :0.98%
Result:Pass

Avg. R/G/B value of the block of bayer raw

=====
[ColorCell#2]
Bayer: B:100.704391, G:269.820148, R:301.021729
Mono: W:619.768738
RGBtoW :630.835693
Ratio :1.08%
Result:Pass

Avg. W of the block of mono raw


=====
[ColorCell#3]
Bayer: B:85.829338, G:169.674576, R:106.657799
Mono: W:334.154877
RGBtoW :346.229095
Ratio :1.18%
Result:Pass

RGBtoW = conversion R/G/B to W

100*ABS(RGBtoW – monoW)/2^(bit depth) %

Check if Ratio < Pass criteria

Each block calculation info



Color Relation Check

Step 8: Analysis Of Failed Case

- If test result is failed:
 - Check if .ini file's setting is proper (ex. bit depth, OB value...)
 - Check if roi area of each raw/block is proper
 - Check if exposure value(shutter/gain) of that case is valid for both bayer and mono sensors
 - Further, need to be discussed

Color Relation Check

Step 9: Troubleshooting - I


- If fill wrong bit depth, there might be mess or too dark loading raw result
 - Ex. Correct bit depth = 10



Color Relation Check

Step 9: Troubleshooting - II

- If fill wrong sensor size, you'll see error msg or mess loading result, please correct file size in .ini





MEDIATEK

everyday genius



CONFIDENTIAL B

Camera Module Check for Auto Focus

Version: V1.0
Release date: 2017-11-29

Document Revision history

Revision	Date	Description
V1.0	2017-11-29	<ul style="list-style-type: none">• First version• Merge “AF basic module check” & “Lens Motor quality Check” to this document.

Purpose

■ Basic check

- Check general auto focus camera module.
- It is designed to guarantee that auto focus can work well.

■ Advance check

- Check camera module auto focus VCM quality.
- It is designed to guarantee that VCM is good enough for application, i.e. dual cam with open loop VCM auto focus .
- For auto focus abnormal issues, this method can also be used to check potential problems in VCM.

Outline

- 1. Basic check (general module check)**
 1. Module Variation
 2. VCM Settling time
 3. OTP Accuracy
 4. Mechanical check
- 2. Advance check (especially for open loop VCM check)**
 1. Linearity Test
 2. Black lash/Hysteresis Test
 3. Accuracy Repeatability/Reliability Test
 4. Lens Posture/Gravity Test

Basic Check

Basic Check


- Basic module check (general module check)
 1. Module Variation
 2. VCM Settling time
 3. OTP Accuracy
 4. Mechanical check

1. Module Variation


- Here list the test items and test conditions:

*environment brightness >400 lux, D65

Item	Module direction	Test distance	Test amount
1 Module variation	Lens forward & Upward	Same as OTP calibration distance	> 100 pcs in forward or upward, and 20pcs for another direction



Forward



Upward

1. Module Variation

Version | Summary | **Module Variation** | VCM Settling time | AF OTP Accuracy | Mechanical check | Advance check | +

- Provide Data: (reference to CameraModuleCheck_for_AutoFocus.xlsx)
 - Record the focus peak Dac* of infinite/macro when forward and upward to excel.

Fill the blank area OTP
100 pcs in forward or upward,
and 20pcs for another direction

No.	Infinite distance		Macro distance		Infinite	Macro
	Forward	Upward	Forward	Upward	Posture Diff.	
#1	376	382	762	743	6	19
#2	312	422	674	738	110	64
#3	296	382	686	734	86	48
#4	348	391	710	776	43	66
#5	308	394	690	732	86	42
#6	332	386	710	709	54	1
#7	332	387	686	759	55	73

*Dac: driver IC position value, if the driver IC use position code is 16bit, it should be remapped to 10bit.

For driver IC target position use 2's complement (2's 補碼), (i.e. On-semi driver IC), we must do a remapping to 0~1023.

1. Module Variation

Version

Summary

Module Variation

VCM Settling time

AF OTP Accuracy

Mechanical check

Advance check



Test Spec.

- It is recommended that
 - $\text{Max}(|\text{unit} - \text{average}|) < \text{Average_OTP_Range} \times 30\%$


		Max Variation					
		Infinite distance		Macro distance		Infinite	Macro
		Forward	Upward	Forward	Upward	Posture Diff.	
Spec		109.02	109.02	109.02	109.02	109.02	109.02
Max Variation(test)		64.96	50.85	83.56	89.75	58.65	86.36842105
%		17.9%	14.0%	23.0%	24.7%	16.1%	23.8%
Result		max	23.0%	Pass			
Spec		max	30%				

2. VCM Settling time(For module house)


- Here list the test items and test conditions:

*environment brightness don't care

Item	Module setting	Test distance	Test amount
2 VCM settling time	forward or upward	N/A	5pcs




Forward



Upward

2. VCM Settling time

- Tools:
 - Laser meter with (1 um) accuracy
 - Test amount: 5 pcs
- Test setting and condition:
 - Module direction: forward or upward
 - Driver IC SRC ON (if available)
 - Check 5 times for average value for each module.
 - Measurement: Amplitude < Step amplitude * 5%
 - Step size:



Step size	Non-PD Sensor	PD Sensor
(OTP Macro – OTP Infinity) x 40%	X	✓
(OTP Macro – OTP Infinity) x 20%	X	✓
(OTP Macro – OTP Infinity) x 5%	✓	✓

2. VCM Settling time

- Provide data: (reference to CameraModuleCheck_for_AutoFocus.xlsx)
 - Fill OTP data, and the start/end of lens moving 10bit dac will auto generate.
 - Fill the result VCM Settling time.

OTP data				
Infinite	Macro	StepSize 40%	StepSize 20%	StepSize 5%
150	700	220	110	28
Step Ratio	From	To	VCM Settling Time	
40%	150	370	9.4	
	370	590	8.6	
	700	480		
	480	260		
20%	150	260		
	370	480		
	590	700		
	700	590		
20%	480	370		
	260	150		
5%	150	178		
	374	402		
	598	626		
	700	672		
5%	476	448		
	252	224		

Fill OTP data →

Auto generate the test Dac →

Fill Test result →

2. VCM Settling time

Version | Summary | Module Variation | **VCM Settling time** | AF OTP Accuracy | Mechanical check | Advance check | +

Test Spec.

- It is recommended that
 - Normal AF settling time < 15 ms;
 - PDAF settling time < 15 ms °

	Step size	VCM Settling time (Unit: ms)
Normal AF	40%	-
Normal AF	20%	-
Normal AF	5%	< 15 ms
Hybrid AF(PD)	40%	< 15 ms
Hybrid AF(PD)	20%	< 15 ms
Hybrid AF(PD)	5%	< 15 ms


3. OTP Accuracy

Version | Summary | **Module Variation** | VCM Settling time | **AF OTP Accuracy** | Mechanical check | Advance check | +


- Module test item:

*environment brightness >400 lux, D65

Item	Test scene/distance	Module direction	Test amount
3 OTP accuracy	As AF OTP calibration	As AF OTP calibration	>10pcs



Forward



Upward

Should the same as AF OTP calibration environment

3. OTP Accuracy

Version | Summary | Module Variation | VCM Settling time | AF OTP Accuracy | Mechanical check | Advance check | +

- Provide data: (reference to CameraModuleCheck_for_AutoFocus.xlsx)

- Fill the focus fine search peak dac of infinite/macro to Excel.
- Fill the OTP value to Excel


		Spec: --Both Max. errors Emacro & Max. errors Einf < (OTP Focus range *15%) --Test quantity: >10 pcs					
Module	OTP value		Fine search result		#	Diff	
	Infinite	Macro	Infinite	Macro		Einf	Emacro
#1	150	500	152	513	#1	7	8
#2	160	510	150	523	#2	5	18
#3	170	520	142	521	#3	3	16
#4	180	530	170	500	#4	25	5
#5	190	540	162	500	#5	17	5
#6	100	460	140	550	#6	5	45
#7	110	470	152	540	#7	7	35
#8	120	480	152	545	#8	7	40
#9	130	490	158	534	#9	13	29
#10	140	550	157	510	#10	12	5

AF OTP Accuracy

Version | Summary | Module Variation | VCM Settling time | AF OTP Accuracy | Mechanical check | Advance check | +

Spec:

- Test quantity: >10 pcs
- For each sample k , calculate errors $|OTP_k - TestValue_k|$ of inf. & macro.
- For each sample, errors E_{macro} & E_{inf} $< (OTP \text{ Focus range} * 15\%)$




4. Mechanical check

Version | Summary | **Module Variation** | VCM Settling time | AF OTP Accuracy | **Mechanical check** | Advance check | +


- Module test item:

*environment brightness >400 lux, D65

Item	Test scene/distance	Module direction	Test amount
4 Mechanical check	As AF OTP calibration	Forward & upward	5pcs




Forward



Upward


4. Mechanical check

- Provide data: (reference to CameraModuleCheck_for_AutoFocus.xlsx)
 - Provide the fine search curve (0~1023, 10bit dac), and confirm below items:
 1. Lens moving is smooth.
 2. Distances from infinite/macro peak to 0&1023 boundary.
 3. Distances from infinite/macro peak to mechanical boundary.



4. Mechanical check

- Naming for curve parts:



4. Mechanical check

Version

Summary

Module Variation

VCM Settling time

AF OTP Accuracy

Mechanical check

Advance check



- Spec of curve parts:

Item	Description	Spec
1	Smooth curve Curve has no burr (as next slide Figure 1) Curve is smooth(as next slide Figure 2)	Curve should be similar to last slide.
2	Distances to 0 &1023 boundaries Peaks should have gap to 0 & 1023 boundaries to avoid AF miss focus at boundary.	DRB > (P2P)*20% DLB > (P2P)*20%
3	Distance to mechanical boundary Peaks should have gap mechanical boundary to avoid AF miss focus at boundary.	DMBM > (P2P)*10% DMBI > (P2P)*10%
4	OTP Range Inf./macro peak distance must have 10% digital code (10bit digital code, 0~1023 => 102) to make sure AF moving is precise.	P2P > 1023*10%

P2P: distance from macro peak to infinite peak

DMBI: Distance to Mechanical boundary (infinite)


DMBM: Distance to Mechanical boundary(macro)

DRB : Distance to 1023 boundary

DLB: Distance to 0 boundary

4. Mechanical check


- Fail case:
 - Figure 1:




4. Mechanical check

- Fail case:
 - Figure 2:

Curve is not smooth



Curve is different from example curve



Advance Check

Advance Check

Version

Summary

Module Variation

VCM Settling time

AF OTP Accuracy

Mechanical check

Advance check




- VCM quality check
 - Test Environment introduction
 - 1. Linearity Test
 - 2. Black lash/Hysteresis Test
 - 3. Accuracy Repeatability/Reliability Test
 - 4. Lens Posture/Gravity Test


Test Environment

- Test equipment:
 - Distance meter with measurement accuracy 1um.
 - Test target is camera module with movable lens unit. The camera module must have lens.
- Test setting:
 - Lens moving for full movable range.
 - Lens moving with specific lens position.
 - AF dac code must be 10bit 0~1023 domain. If not, driver must have a dac code mapping for it.
- Warming up Before Test:
 - Step1 --Warming up camera for 5 min. (keep camera power on 5min)
 - Step2– Trigger lens full scanning or moving, moving interval is 10 dac code (0,10,20,...1020)
- Output (reference to CameraModuleCheck_for_AutoFocus.xlsx)
 - Fill OTP inf./macro data to the excel.
 - Fill measured result to the excel.
 - The tool will calculated results and have a summary


Test Environment



Laser on lens



Measurement Result




LINEARITY TEST

Linearity Test

- **Linearity Test**
 - Lens move from 0,10,20... to 1020 dac code
 - Calculate curve errors %.
- **Test Quantity**
 - 5 pcs module with lens on it.
 - Each module do 1 curve.
- **Calculation**
 - Show in next slide.
- **Test Spec**
 - Result max errors $\epsilon(x) < 5\%$ (within OTP inf./macro range.)

Calculation Linearity Test

- Find the max errors $\varepsilon(x)$




BLACK LASH/HYSTERESIS TEST

Black lash/Hysteresis Test

- **Black lash/Hysteresis Test**
 - Lens move from 0,10,20,... to 1020 dac code
 - Lens move from 1020,1010,... to 0 dac code
- **Test Quantity**
 - 5 pcs module with lens on it.
 - Each module do 2 curves (Moving forward/backward 2 directions).
- **Calculation**
 - Show in next slide.
- **Test Spec**
 - Result max errors $\epsilon(x) < 5\%$ (within OTP inf./macro range.)

Calculation Black lash/Hysteresis Test

- Find the max errors $\varepsilon(x)$



ACCURACY REPEATABILITY/RELIABILITY TEST

Accuracy Repeatability/Reliability Test

- **Accuracy Repeatability/Reliability Test**
 - Lens move from p1,p2,p3,...to p10, and repeats 5 times per module.
 - Here {p1,p2,...p10} is defined as :
 - {OTPinf, OTPinf+interval, OTPinf+interval*2, OTPinf+interval*3, ... OTPinf+interval*9}
 - interval = (OTPmacro – OTPinf)/9
 - Excel will auto generate the p1~p10 value after fill OTP data.
- **Test Quantity**
 - 5 pcs module with lens on it.
 - Each module repeats 5 Times.
- **Calculation**
 - Show in next slide.
- **Test Spec**
 - Result max errors $\epsilon(x) < 5\%$

Calculation Accuracy Repeatability/Reliability Test

(reference to CameraModuleCheck_for_AutoFocus.xlsx)

2. Fill the measurement position shift (um) according to the Dac										
Reliability Test										
Module 1#	Fill the measurement position shift (um)									
Dac	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10
215	259	303	347	391	435	479	523	567	611	
Test1	19.27	41.85	60.78	79.63	101	120.67	140.74	160.34	179.34	216.22
Test2	19.72	40.45	60.23	79.3	101.31	120.92	141.69	158.87	179.17	216.47
Test3	20.8	40.4	60.64	78.25	102.1	120.44	141.26	159.52	179.65	216.37
Test4	19.62	39.82	60.93	80.1	100.68	120.06	142.01	160.42	179.68	216.89
Test5	19.47	40.3	60.4	79.71	101.27	120.01	140.52	160.08	179.62	216.94

$$\text{Errors}(\%): \quad \varepsilon_{pn}(x) = \frac{\text{Max}_{pn} - \text{Min}_{pn}}{\text{Average}_{p_{10}} - \text{Average}_{p_1}} \times 100\%, \quad n = 1 \dots 10$$

LENS POSTURE/GRAVITY TEST

Lens Posture/Gravity Test

■ Lens Posture/Gravity Test

- Set lens upward, and move from 0,10,20... to 1020 dac code
- Set lens downward, and move from 0,10,20... to 1020 dac code.
- Calculate curve errors %.

■ Test Quantity


- 5 pcs module with lens on it.
- Each module results 2 curves (2 postures of upward/downward).

■ Calculation

- Show in next 2 slides.


■ Test Spec

- Posture compensated max. $\varepsilon(x) < 5\%$
- Calculate by the excel.



Calculation Lens Posture/Gravity Test


- Find the max errors $\varepsilon(x)$



Calculation Lens Posture/Gravity Test

- Calculation:
 - The excel “CameraModuleCheck_for_AutoFocus.xlsx” can do regression automatically, and calculate posture result with/without compensated.

Lens Posture Test	w/o compensation	w/ compensation
	40.80%	4.79%
	39.167173	Dac



Summary

- A summary report will show in the excel “summary page”
- Please provide the result excel file to us.





MEDIATEK

everyday genius



CONFIDENTIAL B

Dual Camera Module Reference Notes

Bayer + Bayer | Bayer + Mono | Wide + Tele


2017/08/22

* This document is for reference design. For customized module configuration, please consult with our contact window.

BAYER (13M) + BAYER (5M) STEREO MODULE

Notes

- Basic Requirement
 - Fixed/Autofocus module for main camera
 - Fixed focus for auxiliary camera
 - Less optical distortion to achieve better depth quality
 - Optical lens distortion < 2% (recommend < 1.5%)
 - Identical F. no
 - * – ~~Closed-loop autofocus module~~
- Fixed Focus Distance
 - Back stereo camera: hyper-focus
 - Front stereo camera: 30-40 cm (refer to the lens SPEC.)
- FOV & Baseline
 - Hor./Ver. FOV of auxiliary camera covers Hor./Ver. FOV of main camera according to determined baseline (b)
 - * – Shorter baseline (the shorter, the better)
 - * – If auxiliary camera can't cover main camera, then main camera must be cropped



Example of Stereo Module

	13M	5M
Sensor	IMX258-0AUH5-C	S5K5E2
Lens	Largan 50065B8	Largan 40120A1
FOV	66.2 (H) 51.6 (V)	72.2 (H) 57.3 (V)
Optical distortion	< 2.0%	< 2.0%
F. no	$2.0 \pm 5\%$	$2.0 \pm 5\%$
Baseline		12.0 mm

Estimated Depth Accuracy

- z-table mapping
 - Assume stereo module is ideal and ± 3 pix uncertainty due to the manufacture error of stereo module and limitation of matching algorithm

1920x1080 1.2cm					
Z (cm)	disp (pix)	Z _{min} (cm)	Z _{max} (cm)	Err (%)	
10	186.9	9.84	10.16	1.63	
30	62.3	28.62	31.52	5.06	
60	31.1	54.73	66.39	10.66	
100	18.7	86.17	119.12	19.12	
200	9.3	151.4	294.57	47.29	
400	4.7	243.59	1117.6	179.40	

- Example.
 - For the case that object distance at 100cm, the estimation uncertainty may range between [86.17, 119.12] cm, so that the object located closer than 86.17.0cm and farther than 119.12cm can be separated

Causes of Disparity Uncertainty

- Manufacture geometric error in stereo module
 - Stereo geometry
 - Lens distortion
- Image quality
 - Intensity difference between two input images
 - Image noises
 - Focus scaling effect
 - Focus blur
- Matching algorithms

BAYER (13M) + MONO (13M) STEREO MODULE

Notes

- Basic requirement
 - The same lens for the two cameras
 - The same closed-loop autofocus module for the two cameras
 - Shorter baseline (the shorter, the better)
 - Avoid magnetic interference between two autofocus motors due to short baseline
 - Less optical distortion to achieve better image and depth quality
 - Optical lens distortion < 2% (recommend < 1.5%)

Driver-Ready Camera Module

	13M (Bayer)	13M (Mono)
Sensor	Sony IMX-258	Sony IMX-258BW
Lens	50016A21	50016A21
FOV	63.2 (H) 75.0 (D)	63.2 (H) 75.0 (D)
Optical distortion	< 2.0%	< 2.0%
F. no	2.0 ± 5%	2.0 ± 5%
Baseline		9.8 mm

VCM	TVC-651ABM, Close Loop	TVC-651ABM, Close Loop
-----	---------------------------	---------------------------

Estimated Depth Accuracy

■ z-table mapping


- Assume stereo module is ideal and ± 3 pix uncertainty due to the manufacture error of stereo module and limitation of matching algorithm

1920x1080 0.98 cm				
Z (cm)	disp (pix)	Z _{min} (cm)	Z _{max} (cm)	Err (%)
10	152.9	9.81	10.20	2.00
30	51.0	28.33	31.88	6.25
60	25.5	53.68	68.00	13.34
100	15.3	83.60	124.41	24.41
200	7.6	143.64	329.14	64.57
400	3.8	224.13	1857.87	364.47

WIDE (12M) + TELE (12M) STEREO MODULE

Notes

- Basic requirement
 - Fixed/Autofocus module for wide camera
 - Fixed/Autofocus module for tele camera
 - Closed loop autofocus module is required
 - The same closed loop autofocus module for the two cameras
 - Less optical distortion
 - FOV of wide camera covers FOV of tele camera
 - Parallel Axis
 - Shorter baseline (the shorter, the better)
 - Avoid magnetic interference between two autofocus motors due to short baseline



An example

	13M (Wide)	13M (Tele)
Sensor	Samsung 2M8	Samsung 3M3
Lens	Lagan 9684	Lagan 60018
FOV	83.0	47.3
Optical distortion	< 2.0%	< 2.0%
F. no	$2.0 \pm 5\%$	$2.6 \pm 5\%$
Baseline		8 mm
VCM	Close loop AF	Close loop AF



Stereo Camera System Hardware Setting

STEREO MODULE ERROR TOLERANCE

- * The following error tolerance need to be guaranteed after external force during assembly process and/or drop tests.

Single Camera Module Requirement

	Required Error Tolerances	Note
$(\mu, \emptyset, \vartheta)$ (rotation angle along Z,Y,X-axis)	-	Trivial & Unmeasurable
Optic Center, X-Axis (+/-)	10 pixel	under image scale of 1920*1440
Optic Center, Y-Axis (+/-)	10 pixel	under image scale of 1920*1440
Z-Axis (+/-)	-	Trivial



Single Camera Module Requirement - An Example

Sensor	IMX-258 (13M)	5E2 (5M)
Image size	4208*3120	2560*1920
Pixel size (um)	1.12	1.12
OC tolerance (pixel)	± 22	± 13
OC tolerance (mm)	± 0.025	± 0.015


$$10(\text{px})/1920*4208 \approx 22(\text{px})$$

$$22(\text{px}) * 1.12 \approx 25(\text{um}) = 0.025(\text{mm})$$

$$10(\text{px})/1920*2560 \approx 13(\text{px})$$

$$13(\text{px}) * 1.12 \approx 15(\text{um}) = 0.015(\text{mm})$$


Baseline




Distance between two cameras

- Reference: 12.0 mm (13M+5M) 9.8 mm (13M + 13M)
- Error tolerance: ± 0.1 mm

Vertical Alignment Error



ideal




practical

Vertical alignment

- Reference: 0.0 mm
- Error tolerance: $\pm 0.1 \text{ mm}$

Rotational Error



Roll angle error

- Reference: 0.0°
- Error tolerance: $\pm 1.5^\circ$ (1.0°)


IQC threshold: 1.0°
After assembly and drop tests: 1.5°

The rotation angles indicate the relative rotation from the main camera to the sub camera.

Tilt Error


Yaw angle error

- Reference: 0.0°
- Error tolerance: $\pm 1.5^\circ$ ($\pm 1.0^\circ$)



Pitch angle error

- Reference: 0.0°
- Error tolerance: $\pm 1.5^\circ$ ($\pm 1.0^\circ$)



IQC threshold: 1.0°

After assembly and drop tests: 1.5°

Brief Summary

The error tolerance specification for module vendor OQC

Baseline		Optical Axis			Optical Center	
X-Shift	Y-Shift	R_x - tilt	R_y - tilt	R_z - rot	OC - X	OC - Y
$\pm 0.1\text{mm}$	$\pm 0.1\text{mm}$	$\pm 1.0^\circ$	$\pm 1.0^\circ$	$\pm 1.0^\circ$	$\pm 10 \text{ pixel}$	$\pm 10 \text{ pixel}$

under image size: 1920*1440

The error tolerance after assembly and drop tests

Baseline		Optical Axis			Optical Center	
X-Shift	Y-Shift	R_x - tilt	R_y - tilt	R_z - rot	OC - X	OC - Y
$\pm 0.1\text{mm}$	$\pm 0.1\text{mm}$	$\pm 1.5^\circ$	$\pm 1.5^\circ$	$\pm 1.5^\circ$	$\pm 10 \text{ pixel}$	$\pm 10 \text{ pixel}$

under image size: 1920*1440

Camera Orientation

B+B / B+M


There are only six types of camera orientation under the android rules



- Recommended for Bokeh applications :
 - Rear camera, configuration #1 and #4
 - Front camera, configuration #5

Camera Orientation

W+T



- Major camera for Bokeh applications :
 - Wide: configuration #1 and #4
 - Tele: configuration #2 and #3

Required Information

1. Detailed lens spec of both camera module, respectively
2. Detailed sensor spec of both camera module, respectively
3. Simulation data of lens distortion curve (i.e. simulation data of lens distortion curve with 10.0 cm interval from micro to infinite, say { 10.0, 20.0, ..., 200.0; 300.0; 400.0, 500.0, 750.0, 1000.0 } cm.
4. CRA curve fitness between lens and sensor, for both cameras, respectively
5. Design layout of the stereo camera module
6. [for B+M] Spectrum response of the color filters between mono sensor and color sensor, in terms of { R, G, B, mono} channel


Configuration Table

Customer_Vendor_MT6797_13M+_13M		B+B / B+M
0	Module type	B+B / B+M / W+T
1	Layout configuration (please refer to the right figure)	1 - 6
2	Baseline (mm)	
3	Main camera sensor – model	
4	Main camera sensor - Raw image size (w,h)	
5	Main camera sensor - Raw image - Bayer pattern	
6	Main camera lens – model	
7	Main camera lens - FOV (horizontal, vertical)	
8	Main camera - RI (Relative Illumination) %	
9	Main camera VCM – model	
10	Main camera fix focus distance	
11	Sub camera sensor – model	
12	Sub camera sensor - Raw image size (w,h)	
13	Sub camera sensor - Raw image - Bayer pattern	
14	Sub camera lens – model	
15	Sub camera lens - FOV (horizontal, vertical)	
16	Sub camera - RI (Relative Illumination) %	
17	Sub camera VCM – model	
18	Sub camera fix focus distance	

B+B / B+M



W+T




Example: Configuration Table

Customer_Vendor_MT6797_13M+_13M		
0	Module type	B+B
1	Layout configuration (please refer to the right figure)	1
2	Baseline (mm)	9.8cm
3	Main camera sensor – model	IMX214
4	Main camera sensor - Raw image size (w,h)	4208 3120
5	Main camera sensor - Raw image - Bayer pattern	RGGB
6	Main camera lens – model	Lagan 50016A
7	Main camera lens - FOV (horizontal, vertical)	63.3 49.1
8	Main camera - RI (Relative Illumination) %	36.1
9	Main camera VCM – model	TVC-651ABF
10	Main camera fix focus distance	40cm
11	Sub camera sensor – model	IMX214
12	Sub camera sensor - Raw image size (w,h)	4208 3120
13	Sub camera sensor - Raw image - Bayer pattern	MONO
14	Sub camera lens – model	Lagan 50016A
15	Sub camera lens - FOV (horizontal, vertical)	63.3 49.1
16	Sub camera - RI (Relative Illumination) %	36.1
17	Sub camera VCM – model	TVC-651ABF
18	Sub camera fix focus distance	40cm

B+B / B+M



W+T





MEDIATEK

everyday genius

Copyright © MediaTek Inc. All rights reserved.



CONFIDENTIAL B

Module Layout Guidance

B+B / B+M / W+T

Camera Orientation

B+B / B+M

There are only six types of camera orientation under the android rules



✗



✗




✗



- Recommended for Bokeh applications :
 - Rear camera, configuration #1 and #4
 - Front camera, configuration #5

Camera Orientation


W+T




- Major camera for Bokeh applications :
 - Wide: configuration #1 and #4
 - Tele: configuration #2 and #3

Phone Layout & Module Layout

Phone Layout



Phone Layout with module



REAR CAMERA

MEDIATEK


CONFIDENTIAL B

MEDIATEK CONFIDENTIAL
moredian@moreedian.com USI

Type 1



Top view





Front of the sensor



Real object
(image 成像)



Sensor 成像



Flip

Mirror

X

X




Flip


Mirror

X

O




Flip




Mirror

O

X



Flip



Mirror


O

O

Type 2




Top view




Front of the sensor



Real object
(image成像)




Sensor成像



sensor




sensor 成像




sensor




sensor 成像



sensor



sensor 成像



sensor



sensor 成像

Flip	Mirror
X	X

Flip	Mirror
X	O


Flip	Mirror
O	X

Flip	Mirror
O	O

Type 3




Top view




Front of the sensor




Real object
(image 成像)




Sensor 成像



Flip




Mirror




Flip




Mirror



Flip



Mirror



Flip




Mirror


Type 4




Top view



Real object (image成像)




Sensor成像




Flip Mirror

X X




Flip Mirror

X 0



Flip Mirror

0 X



Flip Mirror

0	0
---	---

● First pixel position

FRONT CAMERA

MEDIATEK


CONFIDENTIAL B

MEDIATEK CONFIDENTIAL
moredian@moredian.com USI

Type 5




Top view




Front of the sensor



Real object
(image 成像)



Sensor 成像





Flip





Mirror



Flip



Mirror




Flip

Mirror

Type 6




Top view




Front of the sensor



Real object
(image成像)



Sensor成像



Flip

Mirror

X

X




Flip

Mirror

X

O





Flip

Mirror

O

X



Flip

Mirror

O

O



CONFIDENTIAL B

II. Module Select



CONFIDENTIAL B

Golden Module Selection

Version: V1.1

Release date: 2017-06-27

Document Revision history

Revision	Date	Description
V1.0	2016-05-17	<ul style="list-style-type: none">• First version
V1.1	2016-06-27	<ul style="list-style-type: none">• Update ISP part for generic estimation

Outline

1. AE
2. AWB
3. AF
 1. OTP Accuracy
 2. Lens tilt
4. LSC
5. ISP

Golden Module Selection Purpose

Golden Module Selection Purpose

- In order to have good camera module sample for camera quality tuning, this document provide methods for select golden modules.
- With this document, vendor or customer can execute camera tuning with correct golden sample by themselves.

Golden Module Selection for AE

Golden Module Selection for AE

- Currently, AE don't need to do golden selection, skip.

Golden Module Selection for AWB

Golden Module Selection for AWB

- **Module amount:**
 - > 10 PCS
- **Test environment:** (no need)
- **Collect data:**
 - Get all modules OTP AWB calibration value (R, GR, GB, &B values).
 - Get OTP AWB golden value (all module should be the same)
- **Choice rule:**
 - Criteria : The difference of R/G and B/G between golden OTP is **less than 1%**.
 - The module satisfied the criteria can be taken as golden sample.

$$(\Delta R/G) = (Golden_OTP(R/G) - UNIT_OTP(R/G))^2$$

$$(\Delta B/G) = (Golden_OTP(B/G) - UNIT_OTP(B/G))^2$$

$$\text{Where } G = (G_b + G_r)/2$$

$$\Delta E = \sqrt{(\Delta R/G)_k + (\Delta B/G)_k} < 1\%$$

Golden Module Selection for AWB

■ Q&A

- Q1: How to check if the AWB OTP data is OK for camera?
- A1: for the unit and golden R/Gr/Gb/B, should satisfy..
 - unit & golden Gb & Gr value should between 140 and 190.
 - $\text{ABS}[(R/G_Unit - R/G_golden) / (R/G_golden)] < 10\%$
 - $\text{ABS}[(B/G_Unit - B/G_golden) / (B/G_golden)] < 10\%$


Golden Module Selection for AF

Golden Module Selection for AF

- AF Golden needs to check 2 items:
 - OTP accuracy:
 - Find the **limit** sample for tuning, and AF table can cover all modules.
 - Lens Tilt:
 - Lens tilt affects all sharpness related items, so we should find out the best lens module without lens tilt.
 - Find the **golden** sample with smallest lens tilt.


OTP Accuracy

- **Module amount:**
 - >20 pcs
- **Test environment:**
 - Star chart.
 - >500 lux, D65.
 - Preview and warm up for >30 seconds.
 - Test Distance is the same with OTP calibration environment.
- **Collect data:**
 - Get all modules OTP infinite/macro values.
 - Get all modules fine search infinite/macro results (by EM mode fullscan).
- **Choice rule:** (find **limit** sample)
 - Find out biggest (OTP infinite value – Fine search infinite result).
 - Find out biggest (Fine search macro result - OTP macro value).



Lens Tilt

- **Module amount:**
 - 20 pcs
- **Test environment:**
 - 5 zone star chart or ISO chart.
 - >500 lux, D65.
 - Preview and warm up for 3 minutes.
 - Test Distance for full chart capture.
- **Collect data:**
 - Get all modules fine search capture results.
- **Choice rule:** (find **golden sample**)
 - If use 5 zones star chart, find smallest sharpness differences between corner 4 zones.
 - If use ISO chart, do SFR calculate for corner 4 zones, and find smallest MTF differences.



Golden Module Selection for AF

- Q&A
 - Q1: How to get AF OTP data?
 - A1: Check MTK log, search keyword: “OTP”

Golden Module Selection for Lens Shading

Golden Module Selection for Lens Shading

- **Lens Shading Golden needs to check 2 items:**
 - Y decay
 - Color shading uniformity

Color Shading Uniformity

- **Module amount:**

- >20 pcs (the more, the better)


- **Test environment:**

- Diffuser
 - DNP
 - Sensor gain: 1X
 - Control G mean(green): **140~180** (8 bit) (after OB subtraction)
 - Disable mirror/flip

- Ask sensor FAE
 - Check sensor spec

- **Collect data:**

- Run “ShadingCalibrationSample.exe” and then “ShadingCorrectionSample.exe”
 - Check “result.txt”



Refer to [20170517_Intro_to_Shading OTP_Tool.pdf](#)

- **Choice rule:**

- Golden: Green one in “Golden” tab
 - Corner: Yellow and Red ones in “Corner” tab


Refer to [20170517_LSC_Golden_Module_Selection.xls](#)

Intro. to Shading OTP Tool

Version Table

Version	Release Date	Comment
1.1	2017/12/5	<ol style="list-style-type: none">1. [P7] detail the description of “Compensation level”2. [P15] Modify criteria part
1.0	2016/06/14	First release

Execution Flow



1.ShadingCalibrationSample.exe

- Description:
 - Generate OTP of shading part
- Usage:
 - 1.ShadingCalibrationSample.exe
- Input:
 - 8bit or 10bit raw
 - slim_param_capture.txt: config file
- Output:
 - after_ob.raw : for verification use
 - after_ob_correct_lo.raw: for verification use
 - image_resize.raw: for verification use
 - eeprom_slim.txt: OTP of shading part

1.ShadingCalibrationSample.exe slim_param_capture.txt

Filename

```
1           //fix shading=0,dynamic_shading=1,slim_shading=2
MONO_4208x3120_8_0.raw    //raw_image_data_in_capture_mode_lo
MONO_4208x3120_8_0.raw    //raw_image_data_in_capture_mode_md
MONO_4208x3120_8_0.raw    //raw_image_data_in_capture_mode_hi
4208x3120_8_coef.txt    //shading_coeff_table_for_capture_raw_image_data
1           //preview_mode=0,take_mode=1
```

Image Size

```
4208 //src_width
3120 //src_height
```

Image bit-depth

```
8           //src_bit_mode
```

Bayer order

```
0           //src_first_pixel
15          //m_x_grid_num
15          //n_y_grid_num
0           //Gr/Gb_apply_the_same_table
0           //src_offset_x0
0           //src_offset_y0
```

Image Size

```
4208 //src_offset_x1
3120 //src_offset_y1
```

1.ShadingCalibrationSample.exe slim_param_capture.txt

Compensation level	33 //block_ave_width 0 //correction_level 1 //gModifyGetMaxVal 1 //gModifySetLscCur 0 //Pattern_distribution_center_X_Pixel_offset 0 //Pattern_distribution_center_Y_Pixel_offset 40 //Max_Pixel_Gain_divide_to_10_for_real_gain -1507556//Pattern_distribution_coef_a_ax5+bx4+cx3+dx2+ex+f 2574222//Pattern_distribution_coef_b_ax5+bx4+cx3+dx2+ex+f -1463111//Pattern_distribution_coef_c_ax5+bx4+cx3+dx2+ex+f 196444//Pattern_distribution_coef_d_ax5+bx4+cx3+dx2+ex+f 0 //Pattern_distribution_coef_e_ax5+bx4+cx3+dx2+ex+f 1000000 //Pattern_distribution_coef_f_ax5+bx4+cx3+dx2+ex+f 0 //OB Value
--------------------	---

1.ShadingCalibrationSample.exe

slim_param_capture.txt

- **Filename:**
 - input raw file name
- **Image Size:**
 - Input raw width and height
- **Image bit-depth**
 - Input raw bit-depth: 8 or 10 bit
- **Bayer order**
 - Input raw bayer order:
 - 0: B, 1: Gb, 2: Gr, 3: R
- **OB Value**
 - Black level: value range is along with image bit-depth.
- **Compensation level**
 - 0 (full compensation)~20 (no compensation)
 - How to know the step size:
 - For example:
 - If set to 0 (full compensation), the measured Max_Y_Decay is 100%.
 - If set to 20 (no shading compensation), the measured Max_Y_Decay keeps unchanged. EX.30%.
 - The step size is $(100\% - 30\%)/20 = 3.5\%$
 - the measured Max_Y_Decay's tolerance is ± 1 step size.
 - » This means if you set the level to 10, the measured Max_Y_Decay is $65\% \pm 3.5\%$

1.ShadingCalibrationSample.exe

- Screenshot

```
Tool Ver VER: 160316  
Tool type This tool is for SENSOR_RGB!  
[LSC] Load argument files: <"lsc_param_preview.txt"> <"lsc_param_capture.txt">  
[LSC] ===== Output coef table =====  
0x59fc4e8a 0x5ea357b2 0x5484499a 0x591952a4  
0x4beb42c5 0x50804aaa 0x45543e4f 0x49254470  
0x3f773a34 0x42f33e91 0x3b033769 0x3e643ab3  
0x38a6364a 0x3c073885 0x384d3686 0x3bd43868  
0x39d13847 0x3e663a09 0x3d883bc7 0x43363dbd  
0x43634149 0x4af943df 0x4ab448b8 0x55064b51  
0x538a5172 0x6102541c 0x5f185d64 0x6fc15f23  
0x699968a4 0x7b2268f8 0x57db4c94 0x5c3b55ba  
0x529747f0 0x570e50de 0x4a264147 0x4e8048f4  
0x43653c98 0x470e42a7 0x3d81386f 0x40ae3cad  
0x38fa359c 0x3c0b38b3 0x36963469 0x39a13691  
0x361734a9 0x39603649 0x37a43660 0x3bd637ef  
0x3b6739cf 0x409e3b96 0x413d3f68 0x485441c5  
0x48ad46db 0x5295495b 0x51a04fe2 0x5e89522c  
0x5ccb5b44 0x6d3c5d2f 0x675765f9 0x78bb66cc  
0x509e45c0 0x54534edb 0x4bfd4203 0x4fab4a75  
  
0x48ef46d5 0x50974707 0x51d64ee2 0x5ba14efb  
0x5bca59cb 0x68ee58cf 0x693667ed 0x795265a6  
0x75307428 0x800070dd 0x00000000 0x00000000  
[LSC] Success to do shading calibration.
```

Msg

MEDIATEK

CONFIDENTIAL B

1.ShadingCalibrationSample.exe Error Code

```
typedef enum{

    CALIBRATION_SUCCESS,           // Success to do shading calibration
    CALIBRATION_FAIL,             // Fail to do shading calibration
    STEP_OK,                      // STEP OK - internal use
    INVALID_RAW_DATA_NULL,        // Fail to load image raw data
    INCOMPLETE_INITIALIZATION,    // Fail to initilize paramters
    EXCEED_SHADING_TABLE_SIZE,   // Fial because of exceeding shading table size
    FAIL_TO_FILL_SHADING_TABLE,  // Fail to fill shading table
    OVERFLOW_HARDWARE_BITS,       // Overflow hardware bits
    WRITE_COEF_FAIL,              // Fail to wrtie coef file
} SHADING_CALIBRATION_RESULT;
```

2.ShadingCorrectionSample.exe

- Description:
 - Verification on calibrated result
- Usage:
 - 2.ShadingCorrectionSample.exe
- Input:
 - after_ob.raw
 - after_ob_correct_lo.raw
 - image_resize.raw
 - lsv_param_capture.txt: config file
- Output:
 - result.txt: verification result

2.ShadingCorrectionSample.exe lsv_param_capture.txt

```
after_ob.raw          //raw_image_data_in_capture_mode_LO
after_ob_correct_lo.raw      //raw_image_after_LSC_LO
after_ob.raw          //raw_image_data_in_capture_mode_MD
after_ob_correct_lo.raw      //raw_image_after_LSC_MD
after_ob.raw          //raw_image_data_in_capture_mode_HI
after_ob_correct_lo.raw      //raw_image_after_LSC_HI
1                      //preview_mode=0,take_mode=1
2104 //src_width
1560 //src_height
8                      //src_bit_mode
0                      //src_first_pixel
```

Image Size

Half of input raw

Image bit-depth
Bayer order

2.ShadingCorrectionSample.exe

lsv_param_capture.txt

- Image Size:
 - Input raw width/2 and height/2
- Image bit-depth
 - Input raw bit-depth: 8 or 10 bit
- Bayer order
 - Input raw bayer order:
 - 0: B, 1: Gb, 2: Gr, 3: R

2.ShadingCorrectionSample.exe

- Screenshot

Tool Ver



Tool type



Msg

```
VER: 160316
This tool is for SENSOR_RWB!
[LSU] Reading EEPROM data format file.
[LSU] Capture Image Width = 800
[LSU] Capture Image Height = 600
[LSU] Capture Offset X = 10
[LSU] Capture Offset Y = 10
[LSU] Capture Shading Table size = 450
[LSU] Load argument files: ("lsv_param_preview.txt") ("lsv_param_capture.txt")
open argument file ("lsv_param_capture.txt") !!
output raw image file name ("after_ob_correct_lo.raw") !!
fscanf MD raw iamgefscanf HI raw iamge[LSU] p_raw_without_LSC_buf size 960000 !!

open raw
Read start
read end
version = 1 memcpy
[LSU] Progressing capture mode raw image data.....
[LSU] capture image pass pre-correction criteria <0.850>!!
[LSU] capture image pass criteria!!
[LSU] Update EEPROM data.
[LSU] Success to do shading correction.
```

2.ShadingCorrectionSample.exe

Error Code

```
typedef enum{

    CORRECTION_SUCCESS,           // Success to do shading correction

    CORRECTION_FAIL,              // Fail to do shading correction

    INIT_PARA_FAIL,                // Fail to initlize paramter for shading correction

    FREE_MEM_FAIL,                 // Fail to free internal allocated memory

    MEM_INIT_FAIL,                  // Fail to allocate internal usage mememory

    IMAGE_LOADING_FAIL,             // Fail to load image data fail

    BUFFER_FOR_LSC_IMAGE_NULL,      // Fail to copy result shading correctio image because there is no buffer for image with shading correction

    GAIN_TABLE_FAIL,                // Fail in gain table check

    LUM_TEST_FAIL,                  // Fail in lum test

    PRECOR_TEST_FAIL,                // Fail in pre correction test

    FALLOFF_TEST_FAIL,               // Fail in falloff test

    COLOR_TEST_FAIL,                 // Fail in color test

}SHADING_CORRECT_RESULT;
```

Criteria

Before Calibration	MONO Sensor	Bayer Sensor	RWB Sensor	Error Code
G mean of <input type="checkbox"/> : (8bit) (After OB subtraction)	140 ~ 180	140 ~ 180	140 ~ 180	LUM_TEST_FAIL
min (R/G) / max (R/G)	> 95%	> 70%	> 70%	PRECOR_TEST_FAIL
min (B/G) / max (B/G)	> 95%	> 70%	> 70%	PRECOR_TEST_FAIL
max(G)/min(G)	< 4	< 4	< 4	OVERFLOW_HARDW ARE_BITS

After Calibration	MONO Sensor	Bayer Sensor	RWB Sensor	Error Code
G mean of <input type="checkbox"/> : (8bit) (After OB subtraction)	140 ~ 180	140 ~ 180	140 ~ 180	LUM_TEST_FAIL
Min (G decay)	> 70%	> 70%	> 70%	FALLOFF_TEST_FAIL
Max (Color diff)	< 5%	< 5%	< (5% / color_gain)	COLOR_TEST_FAIL

Golden Module Selection for ISP Generic Estimation

Golden Module Selection

- Platform Sensor Setting Check
- Select Golden Sample for IQ Tuning
 - RAW Sharpness – MTF50
 - RAW Noise – SNR @ G channel


Platform Sensor Setting Check

- ✓ Ensure no additional sensor modules are activated unexpectedly


Platform Sensor Setting Check

- Check register info from datasheet
- Method: Execute CCT connected to Phone

Example: IMX338	Register address	Configuration	
		Disable	Enable
LSC@Normal	R0x0B00[0]	0	1
LSC@HDR	R0x3000[0]	0	1
Static DPC	R0x0B05[0]	0	1
Dynamic DPC	R0x0B06[0]	0	1
HDR MODE	R0x0220[0]	0	1
CNR@Normal	R0x30A2[1]	0	1
CNR@HDR	R0x3004[1]	0	1
ARNR@Normal	R0x30A2[0]	0	1
ARNR@HDR	R0x3004[0]	0	1



- Operation of reading sensor register value on the fly



- Switch to Tab of Sensor Register
- Select Sensor Register
- Key in Register Address
- Push Read Button and get reading out on Value text box

RAW Sharpness

Pure RAW is captured with normal AE


- ✓ Get golden unit with higher MTF value among samples

RAW Sharpness – EM Setting



- **EM Capture RAW setting**
 - Camera Sensor : Main
 - Capture mode : Normal Capture
 - Capture size : Capture size
 - Capture ratio : 4:3
 - Capture type : Pure Raw
 - Capture number : 1
 - Shutter speed (ms) : 0
 - Sensor gain (1.0=1024) : 0
 - Flicker : 50Hz (China), 60Hz (Taiwan)
 - Strobe Mode : OFF
 - HDR Debug : OFF
 - Shutter Delay : 5 s
 - Shading Table : TSF
 - Multi Pass NR : Auto
 - MFLL : OFF
 - ISO interpolation OFF
 - Flash Calibration : OFF
 - Scene mode : Auto
 - AWB Verification : All OFF
 - Shading Verification : All ON
 - AF : Full Scan
 - Custom Parameter :
 - Capture : Start Preview

RAW Sharpness – FOV (1/2)

- With tripod
- 1000 lux @ Day Light
- Capture distance : 4:3 full screen




RAW Sharpness – FOV (2/2)




RAW Sharpness – Read Raw (1/8)

- A1. Run Imatest “Read Raw “ to...
 - Demosaic pure RAW
 - Frame base AWB
 - save as a PNG for MTF measurement




RAW Sharpness – Read Raw (2/8)

- A2. Choose an extension and place “raw” as been recognized
- A3. Input raw size




RAW Sharpness – Read Raw (3/8)

- A4. Select “Simple White Balance (gray world– darken)”
- A5. Select “Matlab (Gradiend-corrected linear interpolation)”




RAW Sharpness – Read Raw (4/8)

- A6. Select Bayer Order of RAW format
- A7. Select “PNG (always save)” for file type of convert output



RAW Sharpness – Read Raw (5/8)

- A8. Save configuration settings
- A9. Start to convert RAW




A9.

A8.


RAW Sharpness – Read Raw (6/8)

- A10. Select/Multi-Select pure RAW file and click “Open”




RAW Sharpness – Read Raw (7/8)

- A11. Check “Read separated files (default)” if you apply for multi-select
- A12. Click “Yes” for saving file



RAW Sharpness – Read Raw (8/8)

- Output file is stored in the same folder as RAW file



RAW Sharpness – Measure MTF (1/9)


- B1. Use Imatest SFRPlus to...
 - Setup SFRPlus configuration
 - Measure MTF50 for files in a time

B1.




RAW Sharpness – Measure MTF (2/9)

- B2. Select the PNG file which is converted via Imatest Read Raw, then click “Open”



RAW Sharpness – Measure MTF (3/9)

- B3. Select the “3. Center, corners, part-way (9), and check purple rectangles are placed correctly
- B4. Click “Save & close”




B3.

B4.

RAW Sharpness – Measure MTF (4/9)


- B5. Click “Exit”, latter on we will use “SFRPlus Auto” for multi-files measurement in a time



RAW Sharpness – Measure MTF (5/9)


- B6. Push “SFRPlus Auto”

B6.




RAW Sharpness – Measure MTF (6/9)

- B7. Select/Multi-select the PNG file which is converted via Imatest Read Raw, then click “Open”



RAW Sharpness – Measure MTF (7/9)

- B8. Check “Read separated files (default)” if you apply for multi-select
- B9. Click “Yes” for saving file



RAW Sharpness – Measure MTF (8/9)

- B10. When executing SFRPlus Auto is done, open the Results\ xxx.raw_Y_multi.csv under the folder of RAW file


tmp ▶ imatest ▶ Results		Search Results
New folder		Date modi
Name		
1_Capture20100101-010351ISOAutopure_4032x3016_10_3.raw_Y_2_sfrbatch.csv		2017/6/27
1_Capture20100101-010351ISOAutopure_4032x3016_10_3.raw_Y_multi.csv		2017/6/27
1_Capture20100101-010351ISOAutopure_4032x3016_10_3.raw_Y_multi_cpp.png		2017/6/27

tmp ▶ imatest ▶ Results		Search Results
New folder		Date modi
Name		
2_Capture20100101-001433ISOAutopure_4032x3016_10_3.raw_Y_multi.csv		2017/6/27
2_Capture20100101-001433ISOAutopure_4032x3016_10_3.raw_Y_multi_cpp.png		2017/6/27
2_Capture20100101-001433ISOAutopure_4032x3016_10_3.raw_Y_radial.png		2017/6/27

RAW Sharpness – Measure MTF (9/9)

- The cell #B49~B57 are the MTF50 values from patches

Primary results	
N	MTF50 (Cy/Pxl)
1	0.1951
2	0.1138
3	0.0846
4	0.1122
5	0.1062
6	0.1189
7	0.1374
8	0.1131
57	0.1363
10	0.216
11	0.1573
12	0.1241
13	0.1069
14	0.1375
15	0.1441
16	0.1733
17	0.118
18	0.1352



RAW Sharpness - Example

- Example of the MTF selection (4032x3016)

Module 編號	MTF 50 [Cy/Pxl]					Ranking
	MTF 中心	MTF 左上	MTF 右上	MTF 左下	MTF 右下	
1	0.1853	0.1087	0.1074	0.0982	0.1135	8
2	0.1962	0.1112	0.0801	0.1104	0.1027	16
3	0.2389	0.1057	0.1155	0.1145	0.1267	3
4	0.1836	0.1116	0.1218	0.1249	0.1333	8
5	0.2591	0.1061	0.1048	0.1181	0.114	1
6	0.255	0.1061	0.1034	0.1049	0.1049	1
7	0.2058	0.1184	0.1049	0.1262	0.1009	5
8	0.185	0.1034	0.1131	0.1076	0.107	8
9	0.2291	0.1212	0.0997	0.1179	0.1163	5
10	0.1838	0.1105	0.0915	0.12	0.1028	20
11	0.1934	0.1136	0.0811	0.1149	0.094	16
12	0.1992	0.1286	0.1439	0.133	0.1357	8
13	0.2003	0.0992	0.1185	0.1068	0.1318	8
14	0.2206	0.1058	0.0987	0.1099	0.1092	3
15	0.2074	0.1142	0.1136	0.1165	0.1113	5
16	0.2283	0.1022	0.0987	0.0722	0.1019	8
17	0.208	0.0889	0.0928	0.1036	0.0772	8
18	0.2071	0.0991	0.0855	0.1119	0.0993	8
19	0.2048	0.0942	0.0696	0.1117	0.0983	16
20	0.1701	0.1134	0.0918	0.1258	0.0939	16

- Pass Criterial:

- ✓ Higher MTF value of center
(Center 0.25Cy/Pxl: $3016/2/2 = 754$ Lp/pH)
- ✓ Consistent MTF corners
(Expected 40% of center MTF)

- Result:

- ❖ Rank all units
- ❖ Propose acceptable performance
(Green cell in Ranking column)

RAW Noise

- ✓ The SNR of Bayer Green channel reaches 22 dB

Pure RAW is captured with:
Shutter speed 1/30 sec
ISO800
LSB D5000 LV5 (common case)

RAW Noise - ROI


- Check the pure RAW noise in Signal to Noise Ratio **on G channels**

- Sample the center square patch of 5% image width

1/30sec, 8x AGC




(RAW file Demosaiced by AYA)



(RAW Histogram from AYA)


RAW Noise - SNR Steps (1/7)

1. Launch AYA
2. Open image file




RAW Noise - SNR Steps (2/7)

3. Select RAWOpen to browse .raw
4. Open RAW file




RAW Noise - SNR Steps (3/7)

5. Select 10 BitCount
6. Select Little Endian
7. Keyin RAW width and Height
8. Push Apply




RAW Noise - SNR Steps (4/7)

9. Select a Scaling Ratio for display (e.g. /4)




RAW Noise - SNR Steps (5/7)

10. Push RAW History button




RAW Noise - SNR Steps (6/7)

11. Draw a central square of 5% image width



RAW Noise - SNR Steps (7/7)

- ❖ Get SNR by calculation of $20 \times \log(\text{Average}/\text{Standard Deviation})$



- . Don't redraw rectangle
- . Open the next RAW and have result from the same rectangle

RAW Noise - Example

- Check the pure RAW noise in Signal to Noise Ratio on each channels
- Example of the SNR selection

Module 編號	RAW SNR on Gr		
	Average	Standard deviation	Main1 SNR
1	199.49	13.62	23.31
2	195.52	14.31	22.71
3	190.48	13.43	23.03
4	199.32	13.68	23.27
5	196.86	13.45	23.31
6	193.05	13.66	23.01
7	190.16	13.62	22.90
8	192.30	13.53	23.05
9	201.12	13.96	23.17
10	191.67	13.45	23.08
11	189.54	13.51	22.94
12	198.11	13.69	23.21
13	196.45	13.48	23.27
14	190.55	13.57	22.95
15	200.25	13.97	23.13
16	197.35	13.88	23.06
17	197.56	13.85	23.09
18	187.52	13.54	22.83
19	193.12	13.70	22.98
20	192.27	13.49	23.08

- Pass Criterial:
 - ✓ Relatively Higher SNR value
 - ✓ No fixed-pattern noise
- Result:
 - ❖ Propose acceptable performance
(Green cell in Ranking col)

Summary - Capturing Conditions

RAW	Metric	Exposure Time	ISO (AGC)	Illuminant	Chart	ROI
Sharpness	MTF50	Normal AE	D65 1000Lux	SFR Plus	Center 4 corners	
Noise	SNR	33 ms	800	LSB Day	Toward LSB	Central square of 5% image width

Appendix – Equipment List

Item	Reference/Link
SFRPlus Chart	http://store.imatest.com/sfrplus-standard.html
Imatest	http://www.imatest.com/products/imatest-master/
CCT tool	MediaTek CCT V2.0_DEV_xxxx.xx.rar
RAW Analyzer (SNR tool)	AYA, DevWare, or Panther
LSB-111 (SNR Chart)	(take central square of 5% image width as SNR ROI)



MEDIATEK

everyday genius



INTERNAL USE

III. Basic tuning verify





CONFIDENTIAL B

MTK 3A/LSC verification test

Version: V1.0
Release date: 2017-05-12

Document Revision history

Revision	Date	Description
V1.0	2017-05-12	<ul style="list-style-type: none">• First version

Overview





- 3A/LSC verification test
 - Lens shading correction
 - Auto exposure and contrast
 - Auto white balance
 - Auto focus

Lens shading correction



- Luminance/Color uniformity test
 - Test goal:
 - check the luminance and color uniformity in different light conditions..
 - Test requirements:
 - D65, CW, TL84, A and H from Spectra Light conditions and DNP lightbox.
 - Grey chart 18%, Diffuser and Imatest software.
 - Repeat 3 images.
 - Test metric:
 - D65/DNP: Y shading > 75%, Color shading $\Delta C(\text{mean}) < 5$
 - CW, TL84, A and H: Y shading > 65%, Color shading $\Delta C(\text{mean}) < 5$

Lens shading correction

- Imatest software
 - Input images:



- Results:



Auto exposure and contrast

- Auto exposure target test
 - Test goal:
 - check the correct behavior of the exposure algorithm (if it reaches the target exposure.)
 - Test requirements:
 - LSB machine LV5~14, target phone (optional.)
 - Repeat 3 images.
 - Test metric:
 - Measure central 70% luminance value Y, $140 < Y < 220$.
 - Measure central 70% luminance value Y, Target phone $Y \pm 20$ (optional.)



Auto exposure and contrast

- Contrast test

- Test goal:
 - check the correct behavior of the exposure and contrast algorithm
 - Test requirements:
 - Daylight illuminants 700lux, target phone (optional.)
 - Q14 chart (occupied 70% FOV in width)
 - Repeat 3 images.
 - Test metric:
 - Measure Q14: patch1 $Y > 245$,
patch2~19 decreasing progressively,
patch20 < 22.5
 - Measure Q14: patch1~5 target phone $Y +/- 10$,
patch6~15 target phone $Y +/- 15$,
patch16~18 target phone $Y +/- 10$,
patch19~20 target phone $Y +/- 5$ (optional.)



Auto white balance

- Auto white balance accuracy and stability test

- Test goal:
 - check the white balance algorithm accuracy and stability
- Test requirements:
 - Gretag Macbeth color checker (70% FOV in width)
 - D65, CW, TL84, A and H from Spectra Light conditions
 - Repeat 10 images.
- Test metric:
 - Measure grey patch 21~22 by saturation and hue, $S = [\max(R,G,B) - \min(R,G,B)] / \max(R,G,B)$, H (defined as following formula.)
 - Measure $\Delta S = \max(S_1 \sim S_{10}) - \min(S_1 \sim S_{10})$

D65: $S < 0.08$, $\Delta S < 0.03$

TL84: $S < 0.10$, $\Delta S < 0.03$

CW: $S < 0.10$, $\Delta S < 0.03$

A: $0.15 < S < 0.20$, $15 < H < 35$, $\Delta S < 0.03$

H: $0.20 < S < 0.30$, $15 < H < 35$, $\Delta S < 0.03$




$$h = \begin{cases} 0^\circ & \text{if } max = min \\ 60^\circ \times \frac{g-b}{max-min} + 0^\circ, & \text{if } max = r \text{ and } g \geq b \\ 60^\circ \times \frac{g-b}{max-min} + 360^\circ, & \text{if } max = r \text{ and } g < b \\ 60^\circ \times \frac{b-r}{max-min} + 120^\circ, & \text{if } max = g \\ 60^\circ \times \frac{r-g}{max-min} + 240^\circ, & \text{if } max = b \end{cases}$$


Auto focus

■ Auto focus test

- Test goal:
 - check the correctness of Auto focusing result
- Test requirements:
 - Daylight illuminants 700 lux for CAF/TAF and 20 lux for CAF.
 - ISO12233 chart at 60cm and 2m, Star chart at 10cm.
 - For CAF, 10 consecutive shoots and between shoots, the focus must be forced to different distance by moving camera. For TAF, 10 consecutive shoots and between shoots, the focus must be forced to re-focus at the touch ROI (the center of the chart.)
- Test metric:
 - Take 1 image by AF full scan as ground truth image.
 - Check the test images if any following failure happens:
 - Star chart focus failure: blur circle radius is 10% larger than the ground truth image.
 - ISO12233 chart focus failure: resulting line pair number is 20% smaller than the ground truth image.
 - AF search failure: AF cannot stop, AF cannot trigger, AF damping, AF overshoot...



ISO 12233 chart



Star chart



MEDIATEK

everyday genius